

SPILL & CONTAINMENT

- 216** *Spill Containment*
- 218** *Spill Kits - Chemicals and Water*
- 219** *Spill Kits - Hydrocarbons Only*
- 220** *Absorbents*

Global Drum Bund
2 or 4 Drum Polyethylene Spill Pallets

These low-priced polyethylene drum bunds offer effective 4-drum or 2-drum storage with all the benefits and features of any comparable Spill containment pallet on the market. The 4-drum model complies with Australian containment standards, and allows easy two-way fork lift entry for moving when fully loaded. A built-in removable inner plate allows for storage of small containers like 20-litre buckets, pails or bottles. Drain plugs allow spilt liquid to be decanted. The bunds are made from recycled HDPE and is resistant to most industrial chemicals.



Specifications

	4 Drum	2 Drum
Dimensions	127 x 127 x 40 cm	127 x 70 x 42 cm
Capacity	230L	125L
Weight	40kg	36kg
Top lip height	20mm	20mm

Ordering Information

GSC4DRM	Global Drum Bund, 4 drum
GSC2DRM	Global Drum Bund, 2 drum



IBC Spill Bund
Suitable for 1000 and 1500 litre containers

The Global IBC Spill Bund is designed to be placed under an IBC container and catch any leaks that may occur from either dispensing or rupturing.

Bund stand is raised above bund to allow good visibility and easy forklift access from all sides.



Specifications

Dimensions

Top	1700 mm x 1700 mm
Base	1470 mm x 1470 mm
Height	780 mm
Capacity	1825 Litres
Weight	75 kg with frame
Material	Recycled polyethylene
Colour	Black

Ordering Information

GSCDB1500	IBC bund with hot dipped galvanised internal frame
GSCDB1500SS	IBC bund with stainless steel internal frame
GSCDBCOV	IBC bund weather proof cover, fits over IBC with dispensing openings allowing liquid dispensing with cover in place



Mini Bund
Suitable for 20 and 25 litre drums

The Mini Bund is ideal for storing and capturing leaks from those small 20 litre drums. The drum sits up on a galvanised steel frame. The spigot is located over a grate that can hold a 10 litre bucket or similar to drain out some of the drums contents. Any leaks are captured in the 52 litre poly container for later disposal.

Features

- Keeps floor free of drips or slippery liquids
- Easy access for decanting
- Drip or decanting stand
- Light weight at 10 kg
- Removable galvanised steel stand
- Small footprint 650 x 410 x 550mm



Ordering Information

GSCDB25LSSFT	Mini Bund with galvanised steel stand
---------------------	---------------------------------------



Galvanised Drum Bund

Hot dipped galvanised bund designed for flammable liquids or hot work areas. Drums can be stored on the bund or on timber pallets.

The 4 drum bund comfortably holds 4 x 205 litre drums. It will contain 250 litres of spilt liquid which complies with Australian Standards.

The 2 drum bund comfortably holds 2 x 205 litre drums. It will contain 250 litres of spilt liquid which complies with Australian Standards.



Ordering Information

GSLP-4DRM-HD 4 Drum Galvanised Steel drum bund

GSLP-2DRM-HD 2 Drum Galvanised Steel drum bund

**AUSTRALIAN
MADE**

Collapsible Bunds

Applications

- Fuel & Chemical Storage
- Containment in the event of leaks or accidental spills
- Storage of fuel tankers, fuel trailers, drum or transformers
- Unloading of fuel and chemical transport vehicles

Features

- Comes in carry bag
- Light weight
- Limited storage space required
- Fast and easy to erect
- Ends fold down to allow vehicle access
- Ground sheet for protection available as an accessory
- Inside floor protector available as an accessory
- Can be made to accommodate a semi trailer
- Bunds made to custom sizes



Ordering Information

GSLSCS1100 Collapsible Bund, 1.8m x 1.8m x 35cm, PVC

GSLSCB450 Collapsible Bund, 1.5m x 1.2m x 25cm, PVC

Bunds may be made to any size, please specify

**AUSTRALIAN
MADE**

Australian Made Emergency Response Spill Kits

These Spill Kits are a safety necessity for your plant, workshop or site. Easily identifiable and easy-to-use, these kits are available for a variety of spill sizes and applications. There are two types of absorbent material in these kits:

1. Enviroorb - Oil Only Spills

Absorbs hydrocarbons, oils but not water. Enviroorb products are manufactured from polypropylene. Polypropylene absorbs hydrocarbons but is water repellent (hydrophobic). Polypropylene absorbs diesel at 10 times it's own weight and oils at 20 times it's own weight.

2. Unisorb - Universal Spills

Absorbs hydrocarbons, oils, water-based chemicals and solvents. Absorbents for chemical spills are made of the same material as Enviroorb but the addition of a small quantity of surfactant (detergent) during manufacture allows the absorbent to absorb all liquids.

Unisorb Spill Kits - Chemicals & Water

10 Litre Drum Kit

Absorbs 10L

Supplied in 10 litre plastic drum:

- 4 x US10L Sock - 60cm x 6cm
- 6 UP10L x Pillows - 18cm x 18cm
- 25 x CP10L Pads 28cm 32cm
- 1 x 10 litre pail

Ordering Information

GSCSKC10 10 Litre Drum Spill Kit

20 Litre Drum Kit

Absorbs 20L

Supplied in 20 litre plastic drum:

- 1 x UMB2.4 Mini boom 2.4m x 75mm
- 3 UP x Pillows - 34cm x 22cm
- 3 x UM Mat 80cm x 55cm
- 4 x CP Handy Pads 28cm 32cm
- 1 x PBPT Particulate Absorbent
- 1 x 20 litre pail
- 1 x DB Disposal Bag

Ordering Information

GSCSKC20 20 Litre Drum Spill Kit

Fork Lift Spill Kit

Absorbs 36L

Supplied in rugged yellow polyethylene bag and includes:

- 3 x UMB3.6 Mini Booms 3.6m x 75mm
- 1 x SKBFL Fork Lift Spill Kit Bag
- 1 x DB Disposal Bag
- Kit made to fit on most fork lifts

Ordering Information

GSCSKCFL Fork Lift Spill Kit

Station Spill Kit

Absorbs 80L

Supplied in rugged yellow polyethylene bag and includes:

- 3 x UMB2.4 Mini boom 2.4m x 75mm
- 5 x UP Pillows - 34cm x 22cm
- 50 x CP Pads 28cm x 32cm (5mm thick)
- 1 x PTC2.5 Particulate Absorbent 2.5kgs
- 1 x PVCG Gloves PVC
- 3 x DB Disposal bags
- 1 x SKB Spill Kit Bag

Ordering Information

GSCSKCS Station Spill Kit

120 Litre Wheely Bin Kit

Absorbs 120L

Supplied in 120 litre Wheely Bin and includes

- 5 x UMB2.4 Mini boom 2.4m x 75mm
- 8 x UP Pillows - 34cm x 22cm
- 100 x CP Pads 28cm x 32cm (5mm thick)
- 1 x PTC2.5 Particulate Absorbent 2.5kgs
- 1 x PVCG Gloves PVC
- 4 x DB Disposal bags
- 1 x 120 Litre Wheely Bin

Ordering Information

GSCSKC120 120L Wheely Bin Spill Kit

240 Litre Wheely Bin Kit

Absorbs 240L

Supplied in 240 litre Wheely Bin and includes

- 10 x UMB2.4 Mini boom 2.4m x 75mm
- 16 x UP Pillows - 34cm x 22cm
- 200 x CP Pads 28cm x 32cm (5mm thick)
- 2 x PTC2.5 Particulate Absorbent 2.5kgs
- 2 x PVCG Gloves PVC
- 8 x DB Disposal bags
- 1 x 240 Litre Wheely Bin

Ordering Information

GSCSKC240 240L Wheely Bin Spill Kit



GSCSKC120

Envirosorb Spill Kits - Hydrocarbon Only**20 Litre Drum Kit**
Absorbs 20L

Supplied in rugged 20 litre plastic drum:

- 1 x EMB2.4 Mini Boom - 2.4m x 75mm
- 3 EP x Pillows - 34cm x 22cm
- 12 x MBBP Pads - 45cm2 x 5mm
- 4 x CP Pads 28cm X 32cm
- 1 x DB Disposable Bags

Ordering Information

GSCSKH20 20L Drum Spill Kit

Fork Lift Spill Kit
Absorbs 36L

Supplied in rugged yellow polyethylene bag and includes:

- 3 x EMB3.6 Mini Booms 3.6m x 75mm
- 2 x DB Disposable Bags
- Made to fit on most fork lifts

Ordering Information

GSCSKHFL Fork Lift Spill Kit

Petrol Pack (for Vans)
Absorbs 40L

Supplied in rugged yellow polyethylene bag and includes:

- 2 x EMB2.4 Mini Booms - 2.4m x 75mm
- 2 x EP Pillows - 34cm x 22cm
- 12 x MBBP Pads - 45cm2 x 5mm
- 1 x PVCG PVC Gloves
- 2 x DB Disposable Bags

Ordering Information

GSCSKPP Petrol Pack

Service Station Spill Kit
Absorbs 90L

Supplied in rugged yellow polyethylene bag and includes:

- 2 x PBFO2.4 Poly Booms - 2.4m x 100mm dia.
- 2 x PPFO Pillows 58cm x 37cm
- 12 x MBBP Pads 45cm2 x 5mm
- 1 x FS Floorsorb
- 1 x PVCG PVC Gloves
- 3 x DB Disposable Bags

Ordering Information

GSCSKHSS Service Station Spill Kit

Truck Spill Kit
Absorbs 100L

Supplied in rugged yellow polyethylene bag and includes:

- 2 x EMB3.6 Mini Booms 3.6mm x 75mm
- 3 x PPFO Pillows 58cm x 37cm
- 12 x MBBP Pads 45cm2 x 5mm
- 1 x FS Floorsorb
- 1 x PVCG PVC Gloves,
- 3 x DB Disposable Bags

Ordering Information

GSCSKHT Truck Spill Kit

120 Litre Wheely Bin Kit
Absorbs 120L

Supplied in 120 litre Wheely Bin and includes

- 4 x PBFO2.4 Poly Booms - 2.4m x 100mm
- 3 x PPFO Pillows - 58cm x 34cm
- 50 x MBBP Pads - 45cm2 x 5mm
- 1x FS3 Floorsorb - 3kgs
- 1 x PVCG PVC Gloves
- 4 x DB Disposable Bags

Ordering Information

GSCSKH120 120L Wheely Bin Spill Kit

240 Litre Wheely Bin Kit
Absorbs 240L

Supplied in 240 litre Wheely Bin and includes

- 7 x PBFO2.4 Poly Booms - 2.4m x 100mm
- 5 x PPFO Pillows - 58cm x 34cm
- 100 x MBBP Pads - 45cm2 x 5mm
- 1x FS7 Floorsorb - 7kgs
- 2 x PVCG PVC Gloves
- 8 x DB Disposable Bags

Ordering Information

GSCSKH240 240L Wheely Bin Spill Kit



GSCSKH20

ENVIROSORB HYDROCARBON ONLY

Absorbent Booms



Ordering Information

GSCSBM-SH6180	Marine Booms (Snap hook join), 6m x 18cm
GSCSBM-SH3180	Marine Booms (Snap hook join), 3m x 18cm
GSCSBM-SH3125	Marine Booms (Snap hook join), 3m x 12.5cm
GSCSBM-RT6180	Marine Booms (Rope tie join), 6m x 18cm
GSCSBM-RT3180	Marine Booms (Rope tie join), 3m x 18cm
GSCSBM-RT3125	Marine Booms (Rope tie join), 3m x 12.5cm
GSCSBW-SH6	Water Booms w/float (Snap hook join), 6m x 18cm
GSCSBW-SH3	Water Booms w/float (Snap hook join), 3m x 18cm
GSCSBW-RT6	Water Booms w/float (Rope tie join), 6m x 18cm
GSCSBW-RT3	Water Booms w/float (Rope tie join), 3m x 18cm
GSCMB3180	Meltblown Booms (Snap hook join), 3m x 18cm
GSCMB3125	Meltblown Booms (Snap hook join), 3m x 12.5cm
GSCCB3160	All Cotton (Snap hook join), 3m x 16cm

Absorbent Pillows



Ordering Information

GSCPPFO	Large Polypropylene pillow, 58cm x 37cm
GSCEP	Small Polypropylene pillow, 37cm x 22cm
GSCPMP	Small Peatsorb (organic) pillow, 18cm x 34cm

Absorbent Pads & Mats



Ordering Information

GSCMBP	Pads, 10mm thick, 45cm x 45cm
GSCMBBP	Pads, 5mm thick, 45cm x 45cm
GSCMBM	Pads, 10mm thick, 90cm x 90cm
GSCMBBM	Pads, 5mm thick, 90cm x 90cm
GSCDM	Pads Drum Top 205L, 56cm dia.

Absorbent Rolls



Ordering Information

GSCMBR401.1	Oil only Roll, 10mm thick, 40m x 1.1m
GSCMBR40.9	Oil only Roll, 10mm thick, 40m x 0.9m
GSCMBR501	Oil only Roll, 10mm thick, 50m x 1m
GSCMBBR401.1	Oil only Roll, 5mm thick, 40m x 1.1m
GSCMBBR40.9	Oil only Roll, 5mm thick, 40m x 0.9m
GSCMBBR501	Oil only Roll, 5mm thick, 50m x 1m

Mini Absorbent Booms



Ordering Information

GSCEBM3.6	Mini Booms, Polypropylene, 8/Ctn, 3.6m x 7.5cm
GSCEBM2.4	Mini Booms, Polypropylene, 12/Ctn, 2.4m x 7.5cm
GSCEBM1.2	Mini Booms, Polypropylene, 24/Ctn, 1.2m x 7.5cm
GSCPBFO3.6	Mini Booms, Polypropylene, 4/Ctn, 3.6m x 10cm
GSCPBFO2.4	Mini Booms, Polypropylene, 7/Ctn, 2.4m x 10cm
GSCPBFO1.2	Mini Booms, Polypropylene, 14/Ctn, 1.2m x 10cm

**UNISORB
CHEMICALS & WATER
(ALL LIQUIDS)**

Absorbents Range



Ordering Information

GSCCR40.32	Rolls - Meltblown Polypropylene, 5mm thick, 5/ctn, 40m x .32m
GSCCR40.9	Rolls - Meltblown Polypropylene, 5mm thick, 1/pk, 40m x .9m
GSCCP	Pads - Meltblown 5mm thick, 50/pk, 28cm x 32cm
GSCCPP	Pads - Meltblown 5mm thick, 50/pk, 45cm x 45cm
GSCUM	Mats - Meltblown 5mm thick, 20/pk, 80cm x 55cm
GSCUMB3.6	Mini-Booms Polypropylene filling, 8/ctn, 3.6m x 7.5cm
GSCUMB2.4	Mini-Booms Polypropylene filling, 12/ctn, 2.4m x 7.5cm
GSCUMB1.2	Mini-Booms Polypropylene filling, 24/ctn, 1.2m x 7.5cm
GSCPCB2.4	Mini-Booms Polypropylene filling, 7/ctn, 2.4m x 10cm
GSCSBC3.125	Mini-Booms Polypropylene filling, 4/ctn, 3.0m x 12.5cm
GSCUS10L	Sock Polypropylene filling, 70/ctn, 60cm x 6cm
GSCPPC	Pillows - Polypropylene, 10/ctn, 37m x 58m
GSCUP	Pillows - Polypropylene, 40/ctn, 34cm x 22cm
GSCUP10L	Pillows - Polypropylene, 96/ctn, 18cm x 18cm
GSCPTC2.5	Particulate 2.5kg, 6/ctn

- Notes -